



# Naturatex– Alfresco Step by Step

**Step 1** Apply Naturatrim corner beads using Shieldflex 1000



**Step 2** Apply Naturatape and Naturapatch Coarse to joints



**Step 3**  
Apply 1 coat of Alfresco Medium Sand polymer texture to entire surface.



**Step 4**

Apply 1 coat of Alfresco Graincoat polymer texture to entire surface.



**Step 5**

Float Alfresco Graincoat smooth using a Plastic Float.



**Finish**

Alfresco Graincoat finished. Alfresco is Available in several finishes available please see Product Information Sheets for more details.

