



Product Information Sheet



Sheet Number: **0011**

Rev 30-07-07

Features:

- Very Fine Texture
- Tintable
- Flexible
- Easy To Apply
- Low Build Finish
- Pre Mixed
- Thermotex Heat Reflective Version

Benefits:

- Great Ambience
- Not Necessary To Paint After
- Allows for substrate movement
- Brush, nap roller or texture roller
- 1 or 2 coats
- Less labour. No mixing
- Reduces Temp.

Notes: There are many substrates on the market. Please consult Shieldcoast for further information regarding applications not on this sheet.



Provencal Suede (Interior or Exterior uses) Pre Mixed Acrylic Texture

Provencal Suede

Provencal Suede is an acrylic texture paint suitable for most substrates to give a fine suede finish. It can be tinted to your choice of colour, cross brushed, rolled with a nap roller and is suitable for interiors and exteriors. It is premixed and is sold in a 15 litre pail. Provencal Suede is fine finish and is available in a heat reflective version called **Thermotex—Provencal Suede** which reduces temperatures in wall cavities and can even aid in increasing the substrates "R" value.

General Application Guide:

After preparation apply 1 coat of Provencal Suede with a brush or roller choice.

Substrate Application Information:

Fibre Cement:

- Apply Naturapatch Coarse & Naturatape to joints
- Fit Naturatrim plastic angles to corners
- Apply 1 coat of tinted Alfresco Medium Sand by trowel
- Apply 1 coat of Provencal Suede by Nap Roller & Brush

Brick or Block:

- Fit Naturatrim plastic angles to corners
- Mix and apply Naturatex Daudeat High Build by trowel
- Apply 1 coat of tinted Alfresco Medium Sand by trowel
- Apply 1 coat of Provencal Suede by Nap Roller & Brush

AAC panels:

- Fit Naturatrim plastic angles to corners
- Apply Naturapatch Coarse & Naturatape to joints
- Apply 1 coat of tinted Alfresco Medium Sand by trowel
- Apply 1 coat of Provencal Suede by Nap Roller & Brush

Polystyrene panels:

- Fit Naturatrim plastic angles to corners
- Embed Naturamatt to entire surface as an impact coat
- Apply Naturatex Daudeat High Build by trowel
- Apply 1 coat of tinted Alfresco Medium Sand by trowel
- Apply 1 coat of Provencal Suede by Nap Roller & Brush

Note: with polystyrene substrates that have a factory impact coat, apply Naturatape and Naturapatch to all joints. No need to apply Naturatex Daudeat High Build in this case.



Specifications:

(all dry times are considered at 25° C and at 50% humidity)

Surface Dry: 4 -5 hours

Top Coat: 24 hours

Hard Dry: 4 -5 days

Wet Film Thickness: Approx. 240 microns

Dry Film Thickness: Approx. 120 microns

Thinning: No thinning required normally. If desired thin with water sparingly.

Clean Up: Clean up with water

Top Picture: Provencal Suede nap rolled and cross hatch brushed. Provencal Suede comes in 15 litre pails.

See MSDS for safety information