



Stencilshield Step By Step

(Stencilshield over cracked broom finished concrete)

Step 1

Grind out cracks & clean concrete with water blaster

Grind out cracks to a depth of 5-10mm to open cracks up. Apply Mouldshield C as per instructions and clean with a water blaster.



Step 2

Apply primer & repair Concrete cracks

Roll 1 coat of Primer Plus over concrete when dry (not shown)

Apply Slab Repair with spatula to cracks.



Step 3

Apply Stencilshield Base Coat

Apply 1 base coat using a trowel or squeegee to entire surface.



Step 4

Layout the pattern

Using stencil tape or in this case stencil pattern layout pattern across the driveway and hold down with random small amounts of Blue Tac.



Step 5

Apply Stencilshield Top Coat

Apply 2 coats of Stencilshield Top Coat using a Hopper Gun.

(Apply 1 light coat first followed by a second coat.)



Step 6

Apply Covercoat Sealer

Remove pattern the next day and remove Blue Tac.

Apply 1 coat of Covercoat Sealer using Hopper Gun.

Picture: Spraying Stencilshield.
Covercoat Sealer not shown.