

Roofbond Step By Step

Step 1

Clean Roof with Water Blaster

Whirl-A-Way attachment to a Water Blaster shown cleaning a metal roof



Step 2

Mask areas not to be painted

Easy Mask 1200 mm shown



Step 3

Apply Sealer

Airless spray with 517 tip is used to apply Shieldseal W Plus sealer



Step 4

Apply 2 Top Coats

Airless spray with 521 tip is used to apply in this case 2 coats of Thermobond HRC

